Innovatint version 3 Quick Guide

Date: 27-10-2016



Table of contents

1.	Start of the software and purging	2
2.	Create a new order	3
3.	Add a customer to an order	6
4.	Find a returning customer order	8
5.	Refilling a canister	10
6.	Make a custom formula	12



1. Start of the software and purging

Open the software and wait for the machine(s) to be initialized. When needed purge the machine. Put a can in the machine and click on the "OK" (1) button.

Create new order	Order ID 10620 waiting	Order ID 10617 waiting	Order ID 10605 waiting	Order ID 10604 waiting		Custom formula Free dispense Matching
COLOR	:	Search type: 🧮	» 0	V	/iew: Own formu	as Details
Type color code				CUSTOM COLO	ORS	
ASF 1010				Custom (Color 1	
ASF 1011						
ASF 1012			1			
ASF 1013						
ASF 1014						
ASF 1020	e					
ASF 1021						
ASF 1022			1			
						0
PRODUCT					BA	SE: 1

When the purging has finished remove the can and click on the "OK" (1) button.





2. Create a new order

Click on the "Create new order"-button (1). When the program asks to delete an already opened order select "OK". Type in the color code or color name into the field (2) and select the desired color.

demodb 🗸					🜣 Options 🗸 👘 🗕 🔤
inr 1	tin	K.			
Create new order	Customer name unconfirmed	Order ID 10620 waiting	Order ID 10617 waiting	Order ID 10605 waiting	⊗ Clear ★ Custom formula ⊡ Print ⊁ Free dispense ● Matching
COLOR	2	type: 📘	i 0	Vie	ew: Own formulas Details
				CUSTOM COLOR	S
ASF 1010				Custom Co	lor 1
ASF 1011				_	
ASF 1012					
ASF 1013					
ASF 1014					
ASF 1020					
ASF 1021					
ASF 1022					
ACT 1032					
PRODUCT					BASE:
<u>*</u>	Ś	D200	⊠ D800_16	_	

Type in the product name into the field (1) and select the product.

Customer	Order ID 10620	Order ID 10617	Order ID 10605	Clear	Custom formul
OR	ASF 1010 - Aqu	atec SF	warang		Matching
орист 1	arch type: 📘		Custom form	ula 🏋 Free dis	pense
			exterior	good hal	ftone interior
Exterior 2-base clone	С		None	best exc	ellent three
Exterior 2401 AABC	с				
Exterior 2401 AAC	с				
Interior 2-base clone	с			9	
Interior 2401 AABC	С			G	
Interior 2401 AAC	с			and a second sec	
Interior 2401 AAC Extender	C			Canton P	
Interior 2401 AAC Exterioer	0				
	Customer name unconfirme OR DUCT Exterior 2-base clone Exterior 2401 AABC Exterior 2401 AABC Interior 2401 AABC Interior 2401 AABC	Customer name unconfirmed DOR DUCT Exterior 2-base done Exterior 2-base	Customer name unconfirmed DGR ASF 1010 - Aquatec SF DUCT Exterior 2-base done Exterior 2-base done C Interior 2-base done C	Customer name unconfirmed unconfirmed Draer ID 10620 waiting Draer ID 10637 waiting Draer ID 10637 waiting Draer ID 10657 waiting Draer ID 10657 waiting Custom form Exterior 2-base done Exterior 2-base done Exterior 2-base done C Interior 2-base d	Customer name unconfirmed Order ID 10620 waiting Order ID 10620 waiting Order ID 10605 waiting Order ID 10605 waiting I Order ID ID ID ID ID ID ID ID ID ID ID ID ID I



Select the can size (1), set the amount of cans to be tinted (2) and click on the "Dispense"-button (3).

demodb 🗸						🕸 Options 🗸 👘 —
innova	atint					
			a. Second Second Second			
Create	Customer	Order ID	Order ID	Order ID	⊗ Clear	🖞 Custom formula
new <	name	10620	10617	10605	📼 Print	🖌 Free dispense
order	unconfirmed	waiting	waiting	waiting		 Matching
COLOR	ASI	- 1010 – Aqua	atec SF			×
N PRODUCT	Ext	erior 2401 AA	c (1)		в	2 ×
	CAI	N SIZE 11	•]	NUMBER OF (CANS <	12 3
FORMULA	ml	•				
FT 22,18				0	>	DISPENSE
TT 22,79				101	2	CANE
XT 10,47				12		SAVE
						ADD ITEM
		A	SF 1010	Exterior 2401	AAC	DELETE ORDER
0 %			^	EXTRA INFO	^	The Statistics of the second
	C.	200	57 D800 1C		-	
RE	U.	200	0800_16			
2						
6						

Insert the correct can into the machine and click on the "OK"-button (1).

demodb 🗸 🗸					💠 Options 🥆	<u> </u>
innov	/atint	Ти				
Create new order	Customer name preparing	Crder ID 10620 waiting	Order ID 10617 waiting	Order ID 10605 waiting	9 Print	
COLOR		ASF 1010 – Aqua	tec SF			
🗴 PRODUCT		Exterior 2401 AAC	2		BASE: C	
		CAN SIZE 11	Ŧ	NUMBER OF CANS	(1) 2) 3)	>>)
FORMULA FT 22,18 TT 22,79 VT 12,32 XT 10,47	ml	+		Ø		
0%	()	AS	F 1010	Exterior 2401 AAC EXTRA INFO		1
% @	Insert Exterior 2	2401 AAC C 1 and co	2 D800_16 nfirm	_	OK CANCEL	

After the dispense remove the can and click on the "OK"-button (1).



demodb 🗸 🗸					$oldsymbol{\Phi}$ Options \checkmark $ $ —
innov	atint				=00
Create new order	Customer name preparing	Order ID 10620 waiting	Order ID 10617 waiting	Order ID 10605 waiting	Print
COLOR		ASF 1010 - Aquat	tec SF		
N PRODUCT		Exterior 2401 AAC			BASE: C
		CAN SIZE		NUMBER OF CANS	
FORMULA FT 22,18 TT 22,79 VT 12,32 XT 10,47	ml		1010	Exterior 2401 AAC	
× 0	Re	D200	A D800_16		ОК

When multiple cans are to be tinted it will automatically ask for the next can. The amount progress is visible in the can amount selected (1).

demodb 🗸 🗸				🌣 Options 🗸	×
innov	vatint				
Create new order	Customer Ord name C 10 preparing wa	ler ID Order ID 620 10617 iting waiting	Order ID 10605 waiting	Print	
COLOR	ASF 1010	– Aquatec SF			
	Exterior	2401 AAC		BASE: 1	
	CAN SIZE	11 -	NUMBER OF CANS	(1) 2 (3)	
FORMULA FT 22,18 TT 22,79 VT 12,32 XT 10,47 0 %	• Im	ASF 1010	Exterior 2401 AAC EXTRA INFO	^	HISTORY (F6)
<u>×</u> 0	D200	D800_16	_	OK	EL CONTRACTOR



3. Add a customer to an order

Create a new order as seen in chapter two. Before searching for a color code or color name first click on "Customer name" (1).

demodb 🗸 🗸					💠 Options	· · · - · ·
innova		<u>)</u>				
Create new < order	Custor.er name unconfirmed	Order ID 10620 waiting	Order ID 10617 waiting	Order ID 10605 waiting	Clear 🖈 Cu	stom formula ree dispense Matching
🚱 COLOR	5	Search type: 📒	i 0	Vi	iew: Own formulas Det	tails
ASF 1010 ASF 1011 ASF 1012 ASF 1012 ASF 1013 ASF 1014 ASF 1020 ASF 1022 ASF 1022				CUSTOM COLOF	RS	
PRODUCT	8	D200	₩ D800_16	_	BASE:	

Search an existing customer by typing in the customer name (1). When the customer has been found select it.





When the customer has not been found click on the "New customer" section (1).

demodb	Customer data:		Reset	🖨 Options 🗸 📃 —	
in	Customer n: ber:	Customer notes:			
• • • • • •	Name Company	Phone	Email		
C++0	New customer			🛞 Clear 🖈 Custom formula	
Cre				Print & Free dispense	
				The trute opense	
				• Matching	
• •				View: Own formulas Details	
E					ľ
	Street:	Order notes:			ŀ
				om color 1	l
	City:				l
					l
	710				ł
	EINLAND				ŀ
					1
	Discount rate [%]:				ł
					ł
		Order priority:		DACE	ł
	Receive marketing offers?	Normal	•	BASE:	ł
	SAVE	CANCEL			

Fill in all needed data. When finished click on the "Save"-button (1).

demodb	Customer data:	Reset	🌣 Options 🗸 👘 🗕 🗙
ini cre ne orr	Customer name / project number: Alain Company name: Phone number: Email: Email: City: ZIP code: Country: EMU AND (x)	Customer notes:	View: Own formulas Details
* @	Discount rate [%]:	Irder priority: formal v	BASE:

Now continue the order creation as normal.



4. Find a returning customer order

Click on the "History"-tab (1).

Create new order	Customer name unconfirmed	Order ID 10620 waiting	Order ID 10617 waiting	Order ID 10605 waiting	🛞 Clear	Custom formula Free dispense Matching	
COLOR	Sea	rch type: 📒	i * 0	Vie	W: Own formu	las Details	
Type color code					S		
ASF 1010				Custom Col	or 1		(FS)
ASF 1011				_			' INFO
ASF 1012							S
ASF 1013							<u> </u>
ASF 1014							
ASF 1020							
ASF 1021							(F6)
ASF 1022							rory
CC01 734							HISH

Now click on the "Customer"-tab (1) and type in the customer name (2). Select the customer (3) and click on "View" (4).

der	nodb 🗸	,						└ _
	ніят	OPV		1				
Ī	o	2	Customers	Y				
	Q Aamu							Reset fields
	View onl	y active custome	rs			\frown	4	Export
	Customer name	Company name	Phone number	Last order	Orders	3	View	Delete
	Aadolf Aamu	aerandir	19164	6-7-2016 13:40	108		Send email	
	Aamu Aarre	almandil	19165	3-7-2016 11:16	112	V		
	Anto Aanto	anuram	19101	4-7-2018 07.40	133		Details:	
							Aamu Aarre	
							almandil	
							Aarneamrod 2, Aarn	amrod 2
							19165	
							Aamu.Aarre@alman	dil.cs
~								
RY (F6								
listo								
-								
Л								Edit
			Ś	D200	D800_	16		
	父							
	Q						-	
	•							



Now scroll through the list or type in the desired color (1). Select the historic order (2) and when needed to tint again click on the "Tint again"-button (3).

de	modb 🗸									│_ ×
	C'	IER HI	STORY	ВА	ск					
į	1		Custom	ers						
	Q Search			From:			1000 to 1000	To:		Reset fields
	Show hidden	orders		_						3 Export
	Date/Time Site	User	Color	Color Narr Produ	ct Base	e Can size	No. of Cans		Tint again	Use as template
	3-7-2016 :		NOVA MC	Exterio	r 24 C	0,25 l	1	-		
	30-6-2016		NOVA LO:	Interio	r 24 C	0,25 l	1		Fix formula	Feedback
1	26-6-2016		NOVA J01	Exterio	r 24 AA	41	1		Delete	View
	9-6-2016 :		NOVA K1	Interio	r 24 AA	0,25 l	9			
	5-6-2016 :		NC	Interio	r 24 C	0,25 l	1		Details:	
	25-5-2016		1	2 Interio	r 24 C	0,25 l	1		Color formula compone	ents:
	21-5-2016		NO	Interio	r 24 AA	0,25 l	2		FT 📒 RT	🔳 тт 📕 VT
	12-5-2016		NOVA 71	Exterio	r 24 🗛	0,25	1		Notes:	
	8-5-2016		NOVA J10	Interio	r 24 B	0,25 I	1			
	4-5-2016		NOVA F1!	Interio	r 24 AA	0,25 I	1		Dispensed by user:	0
6	1-5-2016		NOVA H0	Interio	r 24 AA	0,25 I	9			
۲Y (F	26-4-2016		NOVA N1	Exterio	r 24 AA	0,25 l	1			
ISTOR	23-4-2016		NOVA L1	Interio	r 24 C	0,25 l	3			
Ŧ	23-4-2016		ASF 1101	Interio	r 24 C	11	1			
	22-4-2016		ASF 1074	Exterio	r 24 🗛	0,25 l	3			
	19-4-2016		ASE 1161	Interio	r 2/ R	0.251	2	•		
	<u>×</u> 0			✓ D200		D80	00_16	_		

When an open order is found the program will ask to delete it. Click on the "OK"-button.

Now follow the instructions on order tinting as described in chapter 2.



5. Refilling a canister

When one or more colorants are low in the canister Innovatint will inform the user in multiple ways.

- Stop or warning sign next to colorant code in formula (A)
- Colorant level gauge (B)
- Dispenser message on driver area (C)



When the colorant is under the warning level (yellow sign) it is still possible to tint. When the colorant is under the critical level (red sign) it is needed to first refill the canister.

Click on the "Gauge"-button (1). Select the colorant can size that is in use (2). The number indicates how many full bottles can be filled (3). Use the "+"-button (4) to add colorant into the program.





Now physically fill the colorant into the machine. Make sure to fill the correct colorant into the correct canister. Repeat the previous steps to refill all colorants. When finished click on the "SAVE"-button (1).





6. Make a custom formula

Go to the product selection section and click on the "Custom formula"-button (1A) or, when available, use the shortcut on the right top of the screen (1B).



Give in the product, base and can size (1). After this give in the formula (2) and type in the color code (3). Finally click on the "OK"-button (4).

demodb 🗸							🗘 Options 🗸 👘 🗕	Х
innovat	int)
Create new order	ustomer O name I confirmed w	rder ID .00 rd 3	Order ID 10617 waiting	Order 1060 waitir	ID 5 1g	🛞 Clear	Custom formula Free dispense	
	MY CO	LOR						
PRODUCT	Search	type:	2	🗙 Custom	formula	Free dis	pense	C INFO (FE)
Exterior 2401 AABC] 📕 FT	10	🔲 кѕ	0	LS	0		
BASE	 17	0	MM	0	MS	0		Ì
B 🗸	MT	0	PT	0	RT	0		L
CAN SIZE	ST ST	0	π	0	VT	0		
UNIT M Addition	RESCALE	0 %	⊂ D800_16		_		ОК	



Now click on the "Dispense"-button (1).

It is also possible to first add the customer details. For this see chapter 3.

Clear 🖈 Custom for Print 🚀 Free dispo	form ispens ching
BASE: B	
	1
DISPENSE SAVE ADD ITEM	SE M
	DER
^	SAVE ADD ITE DELETE OR

Now click on the "OK"-button (1) and follow the instructions.

demodb 🗸		💠 Option	s 🗸 🔰 🗶
innovatin			
Create Customer new name order preparing	Order ID Order ID 10620 10617 waiting waiting	Order ID 10605 waiting	
COLOR	MY COLOR		
PRODUCT	Exterior 2401 AABC	BASE: B	
	CAN SIZE	NUMBER OF CANS << 1 2	
FORMULA mi	MY COLOR NOTES	Exterior 2401 AABC EXTRA INFO	bioose (94) ANOLS
K Insert Exterior 2	D200 D200 D800_16 2401 AABC B 1 I and confirm		OK